


- \* Press **home** button to turn on the gamepad.
- \* Hold **home** button for 3 seconds to turn off the gamepad.
- \* Hold **home** button for 8 seconds to force the gamepad to shut down.



- \* 开机: 按下 [HOME 键]。
- \* 关机: 按住 [HOME 键] 3 秒。
- \* 强制关机: 按住 [HOME 键] 8 秒。

## Switch



- \* Please ensure your Switch system is 3.0.0 or above.
- \* Motion controls, NFC scanning, IR camera, rumble, notification LED, player status LED are not supported, nor can the system be waken up.

### Bluetooth Connection

1. Turn the mode switch to **S**.
2. Press **home** to turn on the gamepad.
3. Hold the **pair** button for 1 second to enter its pairing mode, LED starts to blink rapidly. (This is required for the very first time only)
4. Go to your Switch Home page to click on “Controllers”, then click on “Change grip/order” and wait for the connection.
5. LED becomes solid when the connection is successful.

### Wired Connection

- \* Go to **System Setting > Controllers and Sensors > turn on Pro Controller Wired Communication**

  1. Turn the mode switch to **S**.
  2. Connect the gamepad to your Switch dock via USB cable.
  3. Wait till the gamepad is successfully recognized by your Switch to play

## Switch



- \* 要求 Switch 主机系统版本为 3.0.0 或更高版本。
- \* 不支持六轴体感、震动、NFC 扫描、红外摄像头、通知灯、玩家状态灯、唤醒主机等功能。

### 蓝牙连接

1. 将模式开关移动到 [S] 位置。
2. 按下 [HOME 键] 开启手柄。
3. 按住 [配对键] 约 1 秒至状态指示灯快速闪烁, 进入配对状态。(仅首次连接时需要配对)
4. 打开 Switch 主机 [手柄] - [更改握法 / 顺序], 等待手柄连接。
5. 连接完成后, 状态指示灯常亮。

### 有线连接

- \* 使用前请确保 [设置] - [手柄与感应器] - [Pro 手柄的有线连接] 功能已开启。

  1. 将模式开关移动到 [S] 位置。
  2. 使用 USB 线将手柄连接到 Switch 主机的 USB 端口, 等待系统识别完成后即可使用。

## Android



- \* Please ensure your Android system is 9.0 or above.

### Bluetooth Connection

1. Turn the mode switch to **D**.
2. Press **home** to turn on the gamepad.
3. Hold the **pair** button for 1 second to enter its pairing mode, LED starts to blink rapidly. (This is required for the very first time only)
4. Go to your Android device's Bluetooth setting, and pair with [8BitDo Micro gamepad].
5. LED becomes solid when the connection is successful.

### Wired Connection

1. Turn the mode switch to **D**.
2. Connect the gamepad to your Android device via USB cable, then wait till the gamepad is successfully recognized by your Android device to play.

## Android



- \* 要求 Android 设备系统版本为 Android 9.0 或更高版本。

### 蓝牙连接

1. 将模式开关移动到 [D] 位置。
2. 按下 [HOME 键] 开启手柄。
3. 按住 [配对键] 约 1 秒至状态指示灯快速闪烁, 进入配对状态。(仅首次连接时需要配对)
4. 打开 Android 设备蓝牙, 在搜索到的设备列表中选择 [8BitDo Micro gamepad] 连接。
5. 连接完成后, 状态指示灯常亮。

### 有线连接

1. 将模式开关移动到 [D] 位置。
2. 使用 USB 线将手柄连接到 Android 设备的 USB 端口, 等待系统识别完成后即可使用。

## Keyboard Mode



### Bluetooth Connection

1. Turn the mode switch to **K**.
2. Press **home** to turn on the gamepad.
3. Hold the **pair** button for 1 second to enter its pairing mode, LED starts to blink rapidly. (This is required for the very first time only)
4. Go to your device's Bluetooth setting, and pair with [8BitDo Micro gamepad].
5. LED becomes solid when the connection is successful.

### Wired Connection

1. Turn the mode switch to **K**.
2. Connect the gamepad to your device via USB cable, then wait till the gamepad is successfully recognized by your device to play.

## 键盘模式



### 蓝牙连接

1. 将模式开关移动到 [K] 位置。
2. 按下 [HOME 键] 开启手柄。
3. 按住 [配对键] 约 1 秒至状态指示灯快速闪烁, 进入配对状态。(仅首次连接时需要配对)
4. 打开设备蓝牙, 在搜索到的设备列表中选择 [8BitDo Micro gamepad] 连接。
5. 连接完成后, 状态指示灯常亮。

### 有线连接

1. 将模式开关移动到 [K] 位置。
2. 使用 USB 线将手柄连接到设备的 USB 端口, 等待系统识别完成后即可使用。

## Battery



About 12 hours of play time with a 180mAh built-in battery pack, rechargeable with 1 to 2 hours charging time.

status -	LED indicator -
Charging -	Red LED stays solid
Low battery	Red LED blinks
Fully charged	Red LED turns off

## Safety Warnings



- \* Please always use batteries, chargers, and accessories provided by the manufacturer.
- \* The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- \* Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- \* Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- \* Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

## 电源



内置 180mAh 可充电式锂电池, 可持续使用约 12 小时, 充电时间约 1~2 小时。

电源状态	电源指示灯状态
正在充电	红灯常亮
电量不足	红灯闪烁
充电完成	红灯熄灭

## 安全警示



- \* 请使用制造商的电池、充电器、配件。
- \* 在用户使用第三方的配件时, 制造商不能对用户的安全负责。
- \* 请勿自行拆卸、改装或修理设备。
- \* 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- \* 对设备的任意变动或改装, 将导致制造商对设备不予保修。

## Ultimate Software

Please download the 8BitDo Ultimate Software from [app.8bitdo.com](http://app.8bitdo.com) to customize the buttons on keyboard mode.

## 自定义配置

请访问 [app.8bitdo.cn](http://app.8bitdo.cn) 获取精英软件使用, 可对键盘模式的按键输出进行修改。

## Support



Please visit [support.8bitdo.com](http://support.8bitdo.com) for further information & additional support.



## 技术支持



\* 请访问 [support.8bitdo.cn](http://support.8bitdo.cn) 了解详细信息。

