

PC Engine mini & PC Engine Core Grafx mini & TurboGrafx-16 mini

- 1 – Plug the receiver to your chosen device, blue LED blinks once per cycle
- 2 – Press **home** button on the controller to pair
- 3 – Blue LEDs on both the controller and receiver become solid when connection is successful

PC Engine mini & PC Engine Core Grafx mini & TurboGrafx-16 mini

1. 将接收器插入主机USB端口, 接收器蓝灯闪烁 1 下/次。
2. 轻按手柄 [home] 键即可连接, 连接成功后蓝灯常亮。

Switch





- 1 – Plug the receiver to your Switch, blue LED blinks 4 times per cycle
 - 2 – Press **home** button on the controller to pair
 - 3 – Blue LEDs on both the controller and receiver become solid when connection is successful
- Switch system needs to be 3.0.0 or above. Go to System Setting > Controller and Sensors > turn on Pro Controller Wired Communication
 - Please see button mapping reference for Switch

Switch



1. 将接收器插入 Switch 主机 USB 端口, 接收器蓝灯闪烁 4 下/次。
 2. 轻按手柄 [home] 键即可连接, 连接成功后蓝灯常亮。
- * 要求 Switch 系统版本为 3.0.0 以上并已启用“Pro 手柄的有线连接”(Pro Controller Wired Communication) 功能。
 - * Switch 键位定义请参考下图标注。



battery



status –		LED indicator –
low battery mode	→	red LED blinks
battery charging	→	red LED stays solid
battery fully charged	→	LED turns off

- built-in 180 mAh Li-on with 18 hours of play time
- rechargeable via USB cable with 1 – 2 hour charging time
- Controller turns off in 1 minute with no connection and 15 minutes with connection but no use

电池



电量状态		指示灯状态
电量不足	→	红灯闪烁
充电中	→	红灯常亮
充电完成	→	指示灯熄灭

- * 内置 180 mAh 锂电池, 可持续使用约 18 小时。
- * 充电时间约 1 - 2 小时, 充电完成后指示灯熄灭。
- * 开机后 1 分钟内无连接, 或连接后 15 分钟无操作会自动关机。

Retrieve a lost connection or connect to a new receiver

- 1 – Turn on the controller then press and hold **select** button for 3 seconds. Blue LED starts to rapidly blink
- 2 – Move the controller close to the receiver. Blue LED becomes solid when connection is successful

重新匹配

- * 如果连接丢失或重新配对新接收器, 可开启手柄后长按 [select] 键 3 秒至蓝灯快速闪烁并靠近接收器, 配对成功后蓝灯常亮。

support



- please visit support.8bitdo.com for further information & additional support

固件升级



- * 请访问 <http://support.8bitdo.cn> 了解详细信息。