

### Super Nintendo Entertainment System & Super Family Computer & Analogue Super Nt

- 1 – plug the receiver to your chosen device, blue LED blinks once per cycle
- 2 – press **start** button on the controller to pair
- 3 – blue LEDs on both the controller and receiver become solid when connection is successful

### battery

#### status –

- low battery mode
- battery charging
- battery fully charged



#### LED indicator –

- red LED blinks
- red LED stays solid
- red LED turns off

- built-in 180 mAh Li-on with 18 hours of play time
- rechargeable via USB cable with 1 – 2 hour charging time
- Controller turns off in 1 minute with no connection and 15 minutes with connection but no use


### Retrieve a lost connection or connect to a new receiver

- 1 – Turn on the controller then press and hold **select** button for 3 seconds. Blue LED starts to rapidly blink
- 2 – Move the controller close to the receiver. Blue LED becomes solid when connection is successful

### support



- Please visit [support.8bitdo.com](http://support.8bitdo.com) for further information & additional support



### Super Nintendo Entertainment System & Super Family Computer & Analogue Super Nt

1. 将接收器插入主机端口, 接收器蓝灯闪烁。
2. 轻按手柄 [start] 键即可连接, 连接成功后蓝灯常亮。

### 电池

#### 电量状态

- 电量不足
- 充电中
- 充电完成



#### 指示灯状态

- 红灯闪烁
- 红灯常亮
- 红灯熄灭

- \* 内置 180 mAh 锂电池, 可持续使用约 18 小时。
- \* 充电时间约 1 - 2 小时, 充电完成后指示灯熄灭。
- \* 开机后 1 分钟内无连接, 或连接后 15 分钟无操作会自动关机。

### 重新匹配

- \* 若无法连接或者更换接收器, 可在开启手柄后按住 [select] 键至指示灯快速闪烁, 将手柄靠近接收器重新配对, 配对完成后接收器与手柄指示灯呈常亮显示。

### 固件升级



- \* 以上使用说明如有修改或变动请以网站最新电子版为准, 恕不另行通知。