

Switch



- 1 – Connect SN30 Pro USB controller to your Switch dock via the USB cable
- Switch system version 3.0.0 or above
- Turn on 'Pro Controller Wired Communication'

Windows (X - input)



- 1 – Connect SN30 Pro USB controller to your Windows device via the USB cable
- Windows 10 or above

Turbo function



- 1 – Hold the button you would like to set turbo functionality to and press the STAR button to activate/deactivate turbo functionality
- 2 – LED on the right will blink when the button with turbo function is pressed
- star button = Switch screenshot button on Switch mode

Safety Warnings




- Please always use batteries, chargers, and accessories provided by the manufacturer.
- The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

support



- please visit support.8bitdo.com for further information & additional support



Switch



1. 将 SN30 Pro USB 控制器连接至 Switch 主机底座的任意 USB 端口即可。
- * 要求 Switch 系统版本为 3.0.0 以上并已启用“Pro 手柄的有线连接”(Pro Controller Wired Communication) 功能。

Windows (X - input)



1. 将 SN30 Pro USB 控制器连接至 Windows 设备任意 USB 端口即可。
- * 要求 Windows 系统版本为 Windows 10 或更高版本。

Turbo 连发功能



1. 按住需要设置连发的功能键,再按下[星号键]可开启 / 关闭按键连发功能。
2. 已开启连发的功能键按下时,右侧指示灯会闪烁。
- * 左、右摇杆与方向键不支持连发。
- * Switch 模式下[星号键]功能为截图键。

安全警示



- * 请使用制造商的电池、充电器、配件。
- * 在用户使用第三方的配件时,制造商不能对用户的安全负责。
- * 请勿自行拆卸、改装或修理设备。
- * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- * 对设备的任意变动或改装,将导致制造商对设备不予保修。

固件升级



- * 请访问 support.8bitdo.cn 了解详细信息。

