


- Press the **Home button** to turn on the controller.
- Hold the **Home button** for 3 seconds to turn on the controller.
- Hold the **Home button** for 6 seconds to force the controller off.



- * 开机: 按下 **Home 键**。
- * 关机: 按住 **Home 键** 3 秒。
- * 强制关机: 按住 **Home 键** 6 秒。

Android

- Android 13 or above is required.

Bluetooth Connection

1. Press the **Home button** to turn on the controller.
2. Hold the **Pair button** for 3 seconds to enter its pairing mode, the **Status indicator** will start to blink rapidly. (This is required for the very first time only.)
3. Go to your Android device's Bluetooth list and pair with [SBitDo Ultimate MG], the **Status indicator** will stay solid when the connection is successful.

Android


- * 要求 Android 设备系统版本为 Android 13 或更高版本。

蓝牙连接

1. 按下 **Home 键** 开启手柄。
2. 按住 **配对键** 3 秒至 **状态指示灯** 快速闪烁, 进入配对状态。(仅首次连接时需要配对)
3. 打开 Android 设备蓝牙, 搜索 **SBitDo Ultimate MG** 连接, 连接完成后 **状态指示灯** 常亮。


Turbo Function

- Home button, LSB/RSB, and P1/P2 buttons are not supported.
- The turbo settings will not be saved permanently and will revert to default settings after the controller is powered off or disconnected.



P1/P2 Buttons Configuration

- One button on the controller can be remapped to the **P1 / P2 buttons**.
- Configuration on the **LSB/RSB** are not supported.
- The **Profile LED** will blink continuously when the configured button is pressed.



Fast Button Swap

- The **Profile LED** will blink continuously when the swapped button is pressed, and indicate the function of this button has been changed.
- **D-pad, Home button, LSB/RSB, + start, - select, and P1/P2 buttons** are not supported for the button swap.
- Press and hold the two buttons that need to be configured, then press the **Star button** to activate the Fast Button Swap. Repeat the same procedure or reconnect the controller will deactivate the function.



Battery

Status	LED indicator
Low battery mode	Red LED blinks
Battery charging	Green LED blinks
Battery fully charged	Green LED turns off

- Built-in 300mAh rechargeable battery pack with 13 hours of play time, with a charging time of 90 minutes.
- The controller will automatically shut down if it fails to connect within 1 minute of startup, or if there are no operations within 15 minutes after establishing a connection.
- The controller will not shut down during wired connection.

Safety Warnings

- Please always use batteries, chargers, and accessories provided by the manufacturer.
- The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

Ultimate Software

Please visit app.8bitdo.com to download the **Ultimate Software V2** to get the latest firmware & additional support.


Support

- Please visit support.8bitdo.com for further information & additional support.




连发功能

- * Home 键、左 / 右摇杆、P1、P2 键 不支持连发。
- * 连发功能不会保存, 关机或断开连接后恢复默认。



配置 P1 / P2 键

- * 可将手柄上的单个按键复制到 **P1 / P2 键**。
- * **左 / 右摇杆** 不支持配置。
- * 已配置的按键使用时 **配置指示灯** 会持续闪烁。



快速交换按键

- * 已交换的按键按下时 **配置指示灯** 会持续闪烁表示此按键的功能已变更。
- * **方向键、左 / 右摇杆、减号键、加号键、Home 键、P1、P2 键** 不支持交换。
- * 按住需要交换的两个按键, 再按下 **星号键** 完成交换。重复此操作或重新连接手柄可取消此功能。



电源

电源状态	电源指示灯状态
电量不足	红灯闪烁
正在充电	绿灯闪烁
充电完成	绿灯熄灭

- * 配备 300mAh 可充电式锂电池, 可持续使用约 13 小时, 充电时间约 90 分钟。
- * 开机后 1 分钟内未连接, 或连接后 15 分钟无操作会自动关机。
- * 使用有线连接时不会自动关机。

安全警示

- * 请使用制造商的电池、充电器、配件。
- * 在用户使用第三方的配件时, 制造商不能对用户的安全负责。
- * 请勿自行拆卸、改装或修理设备。
- * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- * 对设备的任意变动或改装, 将导致制造商对设备不予保修。

自定义配置

请访问 app.8bitdo.cn 获取 **精英软件 V2** 使用。

技术支持

- * 请访问 support.8bitdo.cn 了解详细信息。

