
# 猎户座青春版蓝牙手柄

中文



- 开机:按下 home 键。
- 关机:按住 home 键 3 秒。
- 强制关机:按住 home 键 8 秒。

#### Switch

- 要求 Switch 主机系统版本为 3.0.0 或更高版本。
- \*不支持NFC扫描、红外摄像头、HD振动、通知灯等功能。

### 蓝牙连接

- 1 按下 home 键 开启手柄
- 2.按住配对键约3秒至状态指示灯快速闪烁,进入配对状态。(仅首次连接时需要配对)
- 3. 打开 Switch 主机 "手柄" 选项,选择 "更改握法 / 顺序",等待手柄连接。
- 4. 连接完成后,状态指示灯 常亮。

\* 请确保 **设置 - 手柄与感应器 - Pro 手柄的有线连接** 功能已开启。

使用 USB 线将手柄连接到 Switch 主机的 USB 端口,等待系统识别完成后即可使用。

#### 电源

配备 480mAh 可充电式锂电池,可持续使用约 16 小时,充电时间约 2 小时。

电源状态 电源指示灯状态 正在充电 红灯常亮 红灯熄灭

- \* 开机后1分钟内未连接,或连接后15分钟内无操作会自动关机。
- 使用有线连接时手柄不会自动关机。

#### 安全警示

A

- 请使用制造商的电池、充电器、配件
- 在用户使用第三方的配件时,制造商不能对用户的安全负责。
- 请勿自行拆卸、改装或修理设备。
- 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- 对设备的任意变动或改装,将导致制造商对设备不予保修。

# 技术支持






# **SRitDo**

#### Ultimate C Bluetooth Controller

English



- Press the home button to turn on the controller.
- \* Hold the home button for 3 seconds to turn off the controller.
- \* Hold the **home button** for 8 seconds to force the controller off.

# **Switch**

- System requirement: Switch 3.0.0 or above.
- \* NFC scanning, IR camera, HD rumble, and notification LED are not supported.

#### Bluetooth connection

- 1. Press the home button to turn on the controller.
- 2. Hold the pairing button for 3 seconds to enter its pairing mode, the status LED will start to blink rapidly. (This is required for the very first time only)
- 3. Go to your Switch settings--Controllers and Sensors--Change grip/order, then wait for the connection.
- 4. The status LED will remain solid when the connection is successful.

# Wired connection

\* Please ensure the [Pro Controller Wired Communication] is enabled in the system setting Connect the controller to the Switch via a USB cable and wait until the controller is recognized by the system to play.

### **Battery**

16 hours of play time with a 480 mAh built-in lithium battery pack, rechargeable with 2 hours charging time.

status -LED indicator low battery red LED blinks red LED stays solid battery charging battery full charged red LED turns off

- \* The controller will automatically shut down if there is no connection within 1 minute after startup or no activity within 15 minutes after connection.
- \* The controller will not shut down when it's over wired connection.

# **Safety Warnings**



- \* Please always use batteries, chargers, and accessories provided by the manufacturer
- \*The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved
- \* Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- \* Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions
- Any unauthorized changes or modifications to the device will void the manufacturer's warranty



