
8BitDo

猎户座青春版有线手柄

中文



Windows

*要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。 按住 X 键并将手柄连接到 Windows 设备的 USB 端口,等待系统识别完成后, 状态指示灯常亮。

Android / Raspberry Pi

* 要求 Android 设备支持 OTG 功能,详情请咨询设备制造商。 按住 **B 键**并将手柄连接到 Android / Raspberry Pi 设备的 USB 端口,等待系统识别完成后,**状态指示灯**常亮。

连发功能

- *已开启连发功能的按键,按下时状态指示灯会持续闪烁。
- * **方向键、左 / 右摇杆**不支持连发。

按住需要设置连发的功能键,再按下星号键可开启/关闭连发。

安全警示

Δ

- * 请使用制造商的电池、充电器、配件。
- * 在用户使用第三方的配件时,制造商不能对用户的安全负责。
- * 请勿自行拆卸、改装或修理设备。
- * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- * 对设备的任意变动或改装,将导致制造商对设备不予保修。

技术支持








8BitDo

Ultimate C Wired Controller

English



Windows

-

* required system: Windows 10 (1903) or above.

hold X button while connecting the controller to the USB port of your device, wait till the controller is successfully recognized by your Windows, Status LED stays solid.

Raspberry Pi & Android



* OTG support is required on your Android device, please contact your manufacturer for more information. hold B button while connecting the controller to the USB port of your device, wait till the controller is successfully recognized by your device, Status LED stays solid.

Turbo function

0

- $\ensuremath{^*}$ status LED blinks continuously when the button with turbo functionality is pressed.
- * D-pad, joysticks are not included.

hold the button you would like to set turbo functionality to and then press the star button to activate/deactivate its turbo functionality.

Safety Warnings



- * Please always use batteries, chargers, and accessories provided by the manufacturer.
- * The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- * Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- * Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

Support



