



Windows



- required system: Windows 10(1903) or above
- 1 – connect the controller to your Windows device via its USB cable
- 2 – wait till the controller is successfully recognized by your Windows to play, **status LED** becomes solid

Android



- required system: Android 9.0 or above
- OTG support is required on your Android device. Please contact your device manufacturer for more details
- 1 – hold **B button**, connect the controller to your Android device via its USB cable
- 2 – wait till the controller is successfully recognized by your Android to play, **status LED** becomes solid

Switch



- OTG cable is required for Switch Lite
- Switch system needs to be 3.0.0 or above
- go to System Setting > Controller and Sensors > Turn on [Pro Controller Wired Communication]
- NFC scanning, motion control, IR camera, HD rumble, notification LED are not supported, nor can the system be waken up
- 1 – connect the controller to your Switch dock via its USB cable
- 2 – wait till the controller is successfully recognized by your Switch to play, **status LED** becomes solid

Turbo function



- **D-pad, Left stick, Right stick** are not supported
- **status LED** blinks continuously when the button with turbo functionality is pressed
- hold the button you would like to set turbo functionality to and then press the **star button** to activate/deactivate its turbo functionality

Ultimate Software

- It gives you elite control over every piece of your controller: customize button mapping, adjust stick & trigger sensitivity, vibration control and create macros with any button combinations
- please visit app.8bitdo.com for the application

Safety Warnings



- Please always use batteries, chargers, and accessories provided by the manufacturer.
- The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

Support



- Please visit support.8bitdo.com for further information & additional support



连接 Windows 设备



- * 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。
- * 将手柄连接到 Windows 设备的 USB 端口, 等待系统识别完成后, **状态指示灯** 常亮。

连接 Android 设备



- * 要求 Android 设备系统版本为 9.0 或更高版本。
- * 需要 Android 设备配备 USB 端口且支持 OTG 功能, 详情请咨询设备制造商。
- * 按住 **B 键** 不放并将手柄连接到 Android 设备的 USB 端口, 等待系统识别完成后, **状态指示灯** 常亮。

连接 Switch 主机



- * Lite 机型需要使用 OTG 转接线。
- * 要求 Switch 主机系统版本为 3.0.0 或更高版本。
- * 请确保 [设置] - [手柄与感应器] - [Pro 手柄的有线连接] 功能已开启。
- * 不支持 NFC 扫描、六轴体感、红外摄像头、HD 震动、通知灯、唤醒主机等功能。
- * 将手柄连接到 Switch 主机底座的 USB 端口, 等待系统识别完成后, **状态指示灯** 常亮。

连发功能



- * 已开启连发功能的按键, 按下时 **状态指示灯** 会持续闪烁。
- * **方向键、左 / 右摇杆** 不支持连发。
- * 按住需要设置连发的功能键, 再按下 **星号键** 可开启 / 关闭按键连发。

自定义配置

- * 配置后可按下 **配置键** 切换不同的配置, 默认无配置。
- * 请访问 app.8bitdo.cn 获取精英软件使用, 可对手柄按键映射、摇杆灵敏度、扳机键灵敏度、振动强度、宏等功能进行自定义配置。

安全警示



- * 请使用制造商的电池、充电器、配件。
- * 在用户使用第三方的配件时, 制造商不能对用户的安全负责。
- * 请勿自行拆卸、改装或修理设备。
- * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- * 对设备的任意变动或改装, 将导致制造商对设备不予保修。

技术支持



- * 请访问 support.8bitdo.cn 了解详细信息。

